

Dated: 26Jan, 2024

#	RTG #	Structure condition	Function Status				Notes	
			Engine	Gantry	Hoist	Trolley	Missing parts	Comments
1	CR16	Crack repaired	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> Hoist over speed device. 	-
2	CR17	Crack repaired	Running	Moving	Not Moving	Not Moving	-	-
3	CR33	Crack repaired	Running	Moving	Not Moving	Not Moving	-	-
4	CR35	Crack repaired	Running	Moving	Not Moving	Not Moving	-	-
5	CR36	Crack repaired	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> Some relays in trolley panel 	<ul style="list-style-type: none"> Engine start Push button is defected Hoist safety brake sensors not activated.
6	CR37	Crack repaired	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> Fuel filter suction hose and fitting Trolley brake C.B 	<ul style="list-style-type: none"> there is an oil leakage in W.T pipes.
7	CR21	Structure cracks	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> Fuel filter suction hose and fitting 	<ul style="list-style-type: none"> W.T power pack at DS gauge defected

#	RTG #	Structure condition	Function Status				Notes	
			Engine	Gantry	Hoist	Trolley	Missing parts	Comments
8	CR22	Structure cracks	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> Fuel filter suction hose Diesel left anti-collision to container L.S. arm and cable 2x 10A fuses F11 .. system control power. F12 .. I/O power supply. Operator seat 10A fuse 2x 220VAC relays Hoist over speed device. CUR missing from RU (PN:C98043-A1680-L1) 	<ul style="list-style-type: none"> Alternator belt defected. Diesel right anti-collision to container defected. E-room right anti-collision to container defected.
9	CR26	Structure cracks	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> CUR missing from RU (PN:C98043-A1680-L1) Hoist over speed device Hoist wire rope clamp Trolley guide roller Some E-chain units 	<ul style="list-style-type: none"> Engine Problem (engine stopped once running on Idle Speed)

#	RTG #	Structure condition	Function Status				Notes	
			Engine	Gantry	Hoist	Trolley	Missing parts	Comments
10	CR30	Structure cracks	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> • Main engine AVR(MX321) • Suction fuel hose • Two Fuel Fittings • Engine cooling fan • Hub fixation Bolts • Muffler Spring • Alternator Belt • Turbo Oil Inlet pipe • All DS side locating pin Oil hose • DSR lock cylinder hose • 2 Gantry motor (ERR & DSR) • ERL Gantry motor encoder. • W.T power pack at E-Room oil gauge and cover. • CUR Card (C98043-A1680-L1) • ADB Card for RRU. • 3-Safety circuit relay.(3ZX1012-0TK2B-4CA1) CRBE-**-**-RL0002 /SAFTY RELAY • 1 hoist braking unit. • 4 Fuses for hoist drive • 2 PLC I/P module (Cabin) • 1 O/P module (Cabin) • Trolley Drive ADB Card. • Hoist over speed • Trolley encoder • Some E-Chain units 	-

#	RTG #	Structure condition	Function Status				Notes	
			Engine	Gantry	Hoist	Trolley	Missing parts	Comments
11	CR34	Structure cracks	Running	Moving	Not Moving	Not Moving	<ul style="list-style-type: none"> • Engine fan and radiator guards • Phase U pus bar missing from engine. • Engine Pickup Sensor • STC valve • Coolant Pump Fixation Bolts • Oil Pressure Sensors • Inlet and Return Fuel Hose • Gantry brake #04 • Gantry encoder corner 4. • W.T 90 degree push button • Hoist ADB card • CUR of RU • OLM 1 • 11x Omron 220VAC relays • Hoist over speed device • Trolley panel safety relay • Some E-Chain units • H.B needs 2 complete balancers and 2 pins. • 20 Relays • Trolley brake 1,2 C.B 	<ul style="list-style-type: none"> • Muffler is Broken